



NOTES:

1. Locate ball valve and box behind sidewalk.
2. Locate tap within 3 feet of end of main line.
3. Maintain positive grade from main to valve. Use elbow fittings where elevation change does not permit bends as shown.

P:\Engr & CAD\STANDARD DWGS - ALL YEARS\Std Dwgs 2014\Waterline Blowoff Assy 17.dwg

dwc 3-00
DDR

BLOWOFF ASSEMBLY

PAGE NO:

17