



PLAN



ELEVATION



**STRAW BALE DAMS  
ARE NOT SILT FENCE  
REPLACEMENTS**

SECTION A

NOTES:

1. USE STRAW BALES TO SLOW AND CONTROL RUNOFF ON SLOPES AND GULLIES.
2. DO NOT USE STRAW BALES TO REPLACE REQUIRED PERIMETER CONTROL.
3. STRAW BALE EROSION CONTROL IS FOR SHORT TERM USE ONLY. REMOVE WITHIN 1 YEAR OF THEIR PLACEMENT.

P:\Engr & CAD\STANDARD DWGS - ALL YEARS\Std Dwgs 2014\Straw Bale Barrier 30.dwg

# STRAW BALE BARRIER

PAGE NO:

# 30